




Control voltage 230 V~



Extra-low voltage



**Note**  
 Implement the installation, fuse protection, mains isolator, emergency stop switches and safety measures in accordance with local/national regulations.  
 Warning! Earth ye-gn must not be used as a control line.  
 Ensure phases are connected correctly.  
 Never use shockproof plugs.